

DIMMEX- DIMMER-CONTROL EXTERN



The external DIMMEX-DIMMER CONTROL can be used with every battery and lighthead. The external Dimmer-Control is available either with 3-,4- or 5-pin XLR connector. Connect the Dimmer Control between lighthead and battery and the light can be adjusted from low to high. Depending on built-in deep discharge protection, please specify voltage of used battery, when ordering.